



Bosch GCM12SD Dust Collection System

Installation Instructions


IMPORTANT NOTICE: This aftermarket attachment is specifically designed and tested for the model listed above. Use on any other model, or modification of this dust collection system, will void eligibility for refunds. Returns requested due to failure to read this disclaimer will require the buyer to cover return shipping costs. For questions or refund requests, please contact us at Jzwoodshop@outlook.com within 30 calendar days of receiving your product.

Compatibility: This dust collection system is compatible with the 12" Bosch Glide on the Bosch Miter Saw Model GCM12SD.

Step 1A FIRST UNPLUG the saw!! Remove both screws from the top of the stock dust collection attachment.



Step 1B Next remove both screws from the bottom of the stock dust collection attachment. Access these screws from the right side of the saw.




Step 2A Remove the lower cord clip, set screw aside. You will use it later.




Step 3 Remove the guard bracket screw, to allow the flat steel to swing down to access screws behind.



Step 4 Remove 2x left-side rear guard screws. You will replace the screws with our provided screws.




Step 5 Remove the screw from the front right-side rear guard.






Bosch GCM12SD Dust Collection System


Installation Instructions



Step 6 Here is a picture of the saw with the attachment removed.





Step 7 Place chute in position, attach with provided 2x screws on left side. Start the threads, but don't fully tighten.



Step 8 Attach the provided screw on the right side, then fully tighten all 3x screws.



Step 9A Place saw head in down position. Attach hose adapter with clip to lower Arm Hole A. Re-install the screw from step 2A. Next route hose on top of clip & cord under hose.



Liability Disclaimer: This attachment is an aftermarket modification and alters the original design of your saw as provided by the manufacturer. Use of this product may void the manufacturer's warranty and could result in unforeseen changes to the saw's performance. While it's highly effective at minimizing dust, users must ensure all workpieces and offcuts are properly supported, safety guidelines are strictly followed, and all operators are trained in safe miter saw operation. By installing or using this product, you agree to assume full responsibility for its use and release JZ Wood Shop, LLC and all affiliated individuals from any liability associated with the product, its use, or related information. This dust chute is designed to capture debris from the saw blade but may be damaged in the event of kickback or if impacted by a workpiece.

Thank you for supporting our small, family-owned business. More woodworking solutions: <https://jzwoodshopboutique.etsy.com>